

Suppressor Pretreatment

There are several aftermarket products that can be applied to your new suppressor that will reduce the carbon buildup. We recommend using Froglube CLP. Add a small amount (1 to 3cc depending on the model) to the back of the suppressor and disperse with air or attach to weapon and shoot. Adding additional Froglube to suppressor for storage will aid in carbon removal during next use.

MFR7 is also an excellent pretreatment for your suppressor and is available on our website

Elite Iron does not recommend storing the weapon with a hot suppressor attached especially with the muzzle pointed up.

Recommended Cleaning Options

Aftermarket Cleaners - There are a multitude of cleaners that the user may try. Be aware that some products may be highly flammable, and caution should be used when using those products. Any CLR products

Ultrasonic - An excellent way to clean and break up caked on carbon. **NOTE:** Remember to wrap several rubber bands around the suppressor, the bottom of the ultrasonic cleaner as the vibrations against the metal tub will rub the finish off the suppressor.

Steam cleaning - Not everyone has this available but if the user does have this option, it is extremely effective in removing the buildup of carbon.

IMPORTANT!! TITANIUM SUPPRESSORS Please note that you should **NOT** use any type of cleaner that contains Ammonia or Chlorine on Titanium Suppressors.